



**CE-9807FSRK JK WRANGLER & UNLIMITED FRONT SHOCK RELOCATOR KIT
INSTALLATION INSTRUCTIONS & TECHNICAL MANUAL**



Fits

- Front of 2007-2018 Jeep JK Wrangler & Unlimited

Kit Includes

- 2) CE-9807FSRB.....Front Shock Relocator Brackets
- 2) EE-5144CH5.....1/2"-20 x 2.75" Bolts
- 2) EE-51ALNC.....1/2"-20 Stover Nuts
- 4) EE-50WSAEH.....1/2" Washers
- 2) EE-62WSAEH.....5/8" Washers
- 2) EE-63NS.....5/8" Nylock Nuts
- 2) EE-50WUSS9.....Thick Flat Washer - 1/2" x 1 3/8"
(Required for use with some shocks as a spacer.)



Instructions

- 1) Remove stock pin-top shocks and install the shock relocator brackets into the factory shock mount holes. Install the new bolt from the bottom and the nut on top. Use the washer under the nut.
- 2) Install eyelet top shocks into the new brackets. When installing the hardware, install with the the nut towards the front of the vehicle. The thick washer supplied may or may not be used for a spacer depending upon your chosen shock.

