



## CE-9300 JEEP TJ & YJ WRANGLER & LJ UNLIMITED 1" BODY LIFT KIT INSTALLATION INSTRUCTIONS & TECHNICAL MANUAL



### Fits

Fits: TJ Wrangler, TJ Wrangler Unlimited (LJ) & YJ Wranglers 1987-2006.

### Kit Includes

- 11) CE-9300A.....Aluminum Body Lift Spacer
- 6) EE-5072CH8.....1/2"-13 x 4 1/2" Bolt
- 6) EE-50WUSSH.....1/2" Flat Washer
- 5) EE-4360CH8.....7/16"-14 x 3 3/4" Bolt
- 5) EE-43WUSSH.....7/16" Flat Washer
- 2) CE-9300B.....Polyurethane Grille Spacer

### Required Tools

- 5/8" socket & wrench
- 3/4" socket
- Chassis Grease
- Red Loctite
- A safe way to lift the body of your Jeep!



### Instructions

- 1) Start the installation by raising your vehicle's hood and disconnect battery.
- 2) Next, rotate the engine fan so that the blades that are the widest apart from each other are at the bottom so that they do not contact the fan shroud and break it when you lift the body. If you are installing the RockJock 1" lifted motor mounts (highly recommended) at the same time, do the body lift first, and then the motor mounts.
- 3) Using a 5/8" socket (and a wrench in some places), remove all of the stock body mounting bolts EXCEPT for the center one under the door on the passenger's side.
- 4) Lift the driver's side of the body up off of frame. If you have trouble - remember there are 2 inboard body pucks in the rear in front of the gas tank (see photo 1). Also, on some models, unscrewing the gas neck from the side of the body temporarily make things easier.
- 5) Place the new 1" body pucks on top of the dome shaped factory rubber body mounts on all of the driver's side mounts (see photo 2).
- 6) Install all of the driver's side body mount bolts, but do not tighten.
- 7) Release your lifting method and go to the passenger's side and repeat the process of lifting the body and installing all of the body lift pucks with the new bolts.
- 8) Install the body lift puck on top of the factory rubber body mount under the center of the grille. While you are there, pop the factory rubber bumpers on each side of the bottom of the grille out and install the new, supplied urethane bumpers from the body lift kit. Use chassis grease on the new bumpers to ease the installation into the bottom of the grille.
- 9) With a 3/4" socket on the middle 6 and a 5/8" socket on the balance, apply red Loctite and install all of the body mount bolts and torque to 60 ft. lbs.
- 10) Check radiator to fan clearance and fan to fan shroud clearance. If you are not installing a set of the RockJock CE-9200 1" lifted motor mounts, you must remove the fan shroud, redrill the fan shroud mounting holes 1" lower and remount the shroud so that it will clear the fan.
- 11) Re-connect your battery. Reattach your gas neck if you loosened it.
- 12) Re-check the torque on all of the body mount bolts after the first 100 miles.



### CALIFORNIA PROP 65 WARNING

**WARNING:** These products can expose you to chemicals including Chromium, Lead, Lead Compounds, Nickel (Metallic), Nickel Compounds, Diisonyl and Di(2-ethylhexyl) Phthalates (DEHP)(DINP) which are known to the State of California to cause cancer or birth defects or other reproductive harm. For more information, visit [www.P65warnings.ca.gov](http://www.P65warnings.ca.gov)



[WWW.ROCKJOCK4X4.COM](http://WWW.ROCKJOCK4X4.COM)



@ROCKJOCK4X4



/ROCKJOCK4X4



/ROCKJOCK4X4BYJOHNCURRIE

PAGE

1

